



Secure Data Management and FDA-Compliant Measured Data Recording

Brief description

The iLogger21 by INTEMPCO is a paperless recorder for the electronic recording, archiving, and evaluation of process data that fully meets FDA requirements according to 21 CFR Part 11. The iLogger21 has a maximum of 18 universal measurement inputs and is especially designed for the recording of security-related data. Up to 50 different users can log in to the device with their personal password and provide their respective signature if needed. Efficient PC programs are available to evaluate archived data and to configure the iLogger21.



Type 706585/...



Type 706585/..., 444
 (Stainless steel front Ex)

Block structure

Inputs/Outputs

0 to 18 analog inputs max.
 0 to 24 binary inputs/outputs max.
 (maximum of 3 module slots, can be fitted with 6 analog inputs or 3 analog inputs and 8 binary inputs/outputs)

Inputs via interface

additionally
 up to 24 binary inputs

Relay outputs

1 relay (standard)
 6 relays (option)

Display/Operation

Display
 5.5" TFT color display,
 320 x 240 pixels,
 256 colors

Operation
 rotary knob or touchpad
 (left, right, press)

Power supply

AC 100 to 240 V +10/-15 %, 48 to 63 Hz
 AC/DC 20 to 30 V, 48 to 63Hz(ELV)

Interface

as standard
 1x RS232/RS485
 option:
 1x PROFIBUS-DP
 1x Ethernet 10/100 Mbits/sec
 4x USB interfaces
 1x RS232 (barcode)

Meas. data memory

internal memory
 256 Mbytes
 external memory
 CompactFlash card and

18x math channels

27x counters/integrators

Software

Setup program,
 PCA3000, PCC,
 PCS, PCAT

- Conforms to FDA CFR Part 11
- Up to 50 users
- Electronic signature
- Comfortable security management

touchpad

CompactFlash memory card or
 USB memory stick

PCA Communications Software (PCC)

- Integrated web server
- Simultaneous recording of up to 3 batch reports
- Batch control (start, stop, texts) through barcode reader
- Modbus master function
- ATEX approval with stainless steel front

Approvals/marks of conformity (see Technical data)



- Ex II 2G Ex px IIC
- Ex II 2D Ex pD 21 IP65

Technical data

Analog inputs

Thermocouple

Designation	Measuring range	Accuracy ^a
Fe-CuNi L DIN 43710	-200 to +900 °C	±0.1 %
Fe-CuNi J EN 60584	-200 to +1200 °C	±0.1 % from -100 °C
Cu-CuNi U DIN 43710	-200 to +600 °C	±0.1 % from -150 °C
Cu-CuNi T EN 60584	-270 to +400 °C	±0.1 % from -150 °C
NiCr-Ni K EN 60584	-200 to +1372 °C	±0.1 % from -80 °C
NiCr-CuNi E EN 60584	-200 to +1000 °C	±0.1 % from -80 °C
NiCrSi-NiSi N EN 60584	-100 to +1300 °C	±0.1 % from -80 °C
Pt10Rh-Pt S EN 60584	0 to 1768 °C	±0.15 %
Pt13Rh-Pt R EN 60584	0 to 1768 °C	±0.15 %
Pt30Rh-Pt6Rh B EN 60584	0 to 1820 °C	±0.15 % from 400 °C
W3Re/W25Re D	0 to 2495 °C	±0.15 % from 500 °C
W5Re/W26Re C	0 to 2320 °C	±0.15 % from 500 °C
W3Re/W26Re	0 to 2400 °C	±0.15 % from 500 °C
Chromel-copel GOST R 8.585-2001	-200 to +800 °C	±0.15 % from -80 °C
Chromel-alumel GOST R 8.585-2001	-200 to +1372 °C	±0.1 % from -80 °C
PLII (Platinel II)	0 to 1395 °C	±0.15 %
Shortest span	Type L, J, U, T, K, E, N, chromel-alumel, PLII: 100 °C Type S, R, B, D, C, W3Re/W26Re, chromel-copel: 500 °C	
Range start/end	freely programmable within the limits, in 0.1 °C steps	
Cold junction	Pt100 internal or thermostat external constant	
Cold junction accuracy (internal)	±1 °C	
Cold junction temperature (external)	-50 to +150 °C adjustable	
Sampling cycle	Channel 1 to 18: 125 ms in total	
Input filter	2nd order digital filter; filter constant adjustable from 0 to 10.0 sec	
Electrical isolation	see "Electrical data" on page 5 and "Overview of the electrical isolation" on page 18	
Resolution	> 14 bit	
Features	also programmable in °F	

^a The linearization accuracy refers to the maximum measuring range. The linearization accuracy is reduced with short spans.

Resistance thermometer

Designation	Connection circuit	Measuring range	Accuracy ^a	Measurement current
Pt100 EN 60751 (TC = $3.85 \cdot 10^{-3} 1/^{\circ}\text{C}$)	2/3-wire	-200 to +100 °C	±0.5 °C	≈ 250 μA
	2/3-wire	-200 to +850 °C	±0.8 °C	≈ 250 μA
	4-wire	-200 to +850 °C	±0.5 °C	≈ 250 μA
Pt100 JIS 1604 (TC = $3.917 \cdot 10^{-3} 1/^{\circ}\text{C}$)	2/3-wire	-200 to +100 °C	±0.5 °C	≈ 250 μA
	2/3-wire	-200 to +650 °C	±0.8 °C	≈ 250 μA
	4-wire	-200 to +650 °C	±0.5 °C	≈ 250 μA
Pt100 GOST 6651-94 A.1 (TC = $3.91 \cdot 10^{-3} 1/^{\circ}\text{C}$)	2/3-wire, 4-wire	-200 to +100 °C	±0.5 °C	≈ 250 μA
	2/3-wire, 4-wire	-200 to +850 °C	±0.8 °C	≈ 250 μA
Pt500 EN 60751 (TC = $3.85 \cdot 10^{-3} 1/^{\circ}\text{C}$)	2/3-wire, 4-wire	-200 to +100 °C	±0.5 °C	≈ 100 μA
	2/3-wire, 4-wire	-200 to +850 °C	±0.9 °C	≈ 100 μA
Pt1000 EN 60751 (TC = $3.85 \cdot 10^{-3} 1/^{\circ}\text{C}$)	2/3-wire	-200 to +100 °C	±0.5 °C	≈ 100 μA
	2/3-wire	-200 to +850 °C	±0.8 °C	≈ 100 μA
	4-wire	-200 to +850 °C	±0.5 °C	≈ 100 μA
Ni100 DIN 43760 (TC = $6.18 \cdot 10^{-3} 1/^{\circ}\text{C}$)	2/3-wire, 4-wire	-60 to +180 °C	±0.4 °C	≈ 250 μA
Pt50 ST RGW 1057 1985 (TC = $3.91 \cdot 10^{-3} 1/^{\circ}\text{C}$)	2/3-wire	-200 to +100 °C	±0.5 °C	≈ 250 μA
	2/3-wire	-200 to +1100 °C	±0.9 °C	≈ 250 μA
	4-wire	-200 to +100 °C	±0.5 °C	≈ 250 μA
	4-wire	-200 to +1100 °C	±0.6 °C	≈ 250 μA

Designation	Connection circuit	Measuring range	Accuracy ^a	Measurement current
Cu50 (TC = $4.26 \cdot 10^{-3} \text{ 1/}^\circ\text{C}$)	2/3-wire	-50 to +100 °C	±0.5 °C	≈ 250 μA
	2/3-wire	-50 to +200 °C	±0.9 °C	≈ 250 μA
	4-wire	-50 to +100 °C	±0.5 °C	≈ 250 μA
	4-wire	-50 to +200 °C	±0.7 °C	≈ 250 μA
Cu100 GOST 6651-94 A.4 (TC = $4.26 \cdot 10^{-3} \text{ 1/}^\circ\text{C}$)	2/3-wire	-50 to +100 °C	±0.5 °C	≈ 250 μA
	2/3-wire	-50 to +200 °C	±0.9 °C	≈ 250 μA
	4-wire	-50 to +100 °C	±0.5 °C	≈ 250 μA
	4-wire	-50 to +200 °C	±0.6 °C	≈ 250 μA
Connection circuit	2-, 3-, or 4-wire circuit			
Shortest span	15 °C			
Sensor lead resistance	max. 30 per conductor for 3-wire/4-wire circuit max. 10 per conductor for 2-wire circuit			
Range start/end	freely programmable within the limits, in 0.1 °C steps			
Sampling cycle	Channel 1 to 18: 125 ms in total			
Input filter	2nd order digital filter; filter constant adjustable from 0 to 10 sec			
Electrical isolation	see "Electrical data" on page 5 and "Overview of the electrical isolation" on page 18			
Resolution	> 14 bit			
Features	also programmable in °F			

^a The linearization accuracy refers to the maximum measuring range. The linearization accuracy is reduced with short spans.

Resistance transmitter and potentiometer

Designation	Measuring range	Accuracy ^{1a}	Measurement current
Resistance transmitter	up to 4000 Ω	±4 Ω	≈ 100 μA
Potentiometer	< 400 Ω	±400 mΩ	≈ 250 μA
	≥ 400 Ω to 4000 Ω	±4 Ω	≈ 100 μA
Connection circuit	resistance transmitter: 3-wire circuit potentiometer: 2-/3-/4-wire circuit		
Shortest span	60Ω		
Sensor lead resistance	max. 30 per conductor for 4-wire circuit max. 10 per conductor for 2-/3-wire circuit		
Resistance values	freely programmable within the limits, in 0.1 steps		
Sampling cycle	Channel 1 to 18: 125 ms in total		
Input filter	2nd order digital filter; filter constant adjustable from 0 to 10.0 sec		
Electrical isolation	see "Electrical data" on page 5 and "Overview of the electrical isolation" on page 18		
Resolution	> 14 bit		

^a The linearization accuracy refers to the maximum measuring range. The linearization accuracy is reduced with short spans.

Input for DC voltage, DC current

Basic range	Accuracy ^a	Input resistance
-12 to +112 mV	±100 μV	$R_E \geq 1 \text{ M}\Omega$
-10 to +210 mV	±240 μV	$R_E \geq 470 \text{ k}\Omega$
-1.5 to +11.5 V	±6 mV	$R_E \geq 470 \text{ k}\Omega$
-0.12 to +1.12 V	±1 mV	$R_E \geq 470 \text{ k}\Omega$
-1.2 to +1.2 V	±2 mV	$R_E \geq 470 \text{ k}\Omega$
-11.2 to +11.2 V	±12 mV	$R_E \geq 470 \text{ k}\Omega$
Shortest span	5mV	
Range start/end	freely programmable within the limits in 0.01 mV steps	
-1.3 to +22 mA	±20 μA	burden voltage ≤ 3 V
-22 to +22 mA	±44 μA	burden voltage ≤ 3 V
Shortest span	0.5mA	
Range start/end	freely programmable within the limits in 0.01 mA steps	
Overrange/underrange	according to NAMUR NE 43	
Sampling cycle	Channel 1 to 18: 125 ms in total	



Basic range	Accuracy ^a	Input resistance
Input filter	2nd order digital filter; filter constant adjustable from 0 to 10.0 sec	
Electrical isolation	see "Electrical data" on page 5 and "Overview of the electrical isolation" on page 18	
Resolution	>14 bit	

^a The linearization accuracy refers to the maximum measuring range. The linearization accuracy is reduced with short spans.

Transducer short circuit/break

	Short-circuit ^a	Break ^a
Thermocouple	not detected	detected
Resistance thermometer	detected	detected
Resistance transmitter	not detected	detected
Potentiometer	not detected	detected
Voltage $\leq \pm 210$ mV	not detected	detected
Voltage $> \pm 210$ mV	not detected	not detected
Current	not detected	not detected

^a Programmable reaction of device, e.g. triggering alarm

Binary inputs/outputs (option)

Input or output	configurable as input or output
Number	8, 16 or 24, depending on the device version, to DIN VDE 0411, Part 500; max. 25 Hz, max. 32 V
Input	<ul style="list-style-type: none"> level counting frequency logic "0": -3 to +5 V (input current max. ± 1 mA), logic "1": 12 to 30 V ($2.5 \text{ mA} \leq \text{input current} \leq 5 \text{ mA}$) 8 Hz
High-speed input	the first two binary inputs of each module (B1, B2, B9, B10, B17, B18), if the module is not fitted with relays or 6 analog inputs <ul style="list-style-type: none"> task counting frequency count function, e.g. for flow measurement 10 kHz
Output	<ul style="list-style-type: none"> type level sampling cycle open-collector output, switches relative to positive voltage logic "0": transistor is inhibited (max. permissible voltage across switching transistor 30 V, max. leakage current 0.1 mA) logic "1": transistor is switched on (max. voltage across switching transistor 1.6 V, max. current 50 mA) at least 1 sec (1 Hz)

Outputs

1 relay (ex-factory)	changeover (SPDT), 3 A, 230 V AC ^a
6 relays (option)	changeover (SPDT), 3 A, 230 V AC ^{a, b}

^a With resistive load.

^b It is not permissible to mix SELV circuits and supply circuits.

Interfaces

RS232/RS485 (connector 7)	Qty. 1, switchable between RS232 and RS485
<ul style="list-style-type: none"> protocol baud rate modem connector external inputs 	Modbus master, Modbus slave and barcode reader 9600, 19200, 38400 can be connected SUB-D via the Modbus master/slave function, 24 analog and 24 binary

RS232 for barcode reader (connector 2)	<ul style="list-style-type: none"> protocol baud rate connector external inputs 	Qty. 1 Modbus master, Modbus slave and barcode reader 9600, 19200, 38400 SUB-D via the Modbus master/slave function, 24 analog and 24 binary
Ethernet (connector 6)	<ul style="list-style-type: none"> quantity protocols baud rate connector data format 	max. 1 TCP, IP, HTTP, DHCP, SMTP, ModbusTCP 10 Mbits/sec, 100 Mbits/sec RJ45 HTML
USB host (connector 5)	<ul style="list-style-type: none"> quantity use max. current 	2 (or 1 with stainless steel front), connector 5 and front connector (not with stainless steel front); no parallel operation for connecting a memory stick 100 mA
USB device (connector 15)	<ul style="list-style-type: none"> quantity use 	2 (or 1 with stainless steel front), connector 15 and front connector (not with stainless steel front); no parallel operation for connecting to the (master) computer

Screen

Resolution/size	320 × 240 pixels/5.5"
Type/number of colors	TFT color screen/256 colors
Screen refresh rate	> 150 Hz
Brightness setting	adjustable on instrument
Screen saver (switch-off)	through waiting time or control signal

Electrical data

Supply voltage (switch-mode PSU)	AC 100 to 240 V +10/-15 %, 48 to 63Hz or AC/DC 20 to 30 V, 48 to 63Hz (ELV)
Electrical safety	to EN 61010, Part 1, August 2002 overvoltage category II, pollution degree 2
Protection class I	terminal for PE conductor
Test voltages (type test)	
<ul style="list-style-type: none"> mains supply circuit to meas. circuit 	with AC supply: 2.3 kV/50 Hz, 1 min, with AC/DC supply: 2.3 kV/50 Hz, 1 min
<ul style="list-style-type: none"> mains supply circuit to housing (protective conductor) 	with AC supply: 2.3 kV/50 Hz, 1 min, with AC/DC supply: 2.3 kV/50 Hz, 1 min
<ul style="list-style-type: none"> measuring current circuits to measuring current circuit and housing 	500 V/50 Hz, 1 min
<ul style="list-style-type: none"> electrical isolation between analog inputs 	up to 30 V AC and 50 V DC
Supply voltage error	< 0.1 % of range span
Power consumption	approx. 40 VA
Data backup	CompactFlash memory card
Electrical connection	
<ul style="list-style-type: none"> mains supply and relays 	at rear through pluggable screw terminals, 5.08 mm raster, max. conductor cross-section $\leq 2.5 \text{ mm}^2$ or $2 \times 1.5 \text{ mm}^2$ with ferrules
<ul style="list-style-type: none"> analog and binary inputs 	at rear through pluggable screw terminals, 3.81 mm raster, max. conductor cross-section $\leq 1.5 \text{ mm}^2$

Environmental influences

Ambient temperature range	0 to +50 °C
Ambient temperature effect	0.03 %/ °C
Storage temperature range	-20 to +60 °C
Climatic conditions	≤ 75 % relative humidity, no condensation
EMC	EN 61326-1
<ul style="list-style-type: none"> interference emission immunity to interference 	Class A - only for industrial use - to industrial requirements

Housing

Housing front	zinc die-casting, optionally in stainless steel (extra code)
Housing type	housing for flush-panel mounting to IEC 61554, in stainless steel
Bezel size	144 mm × 144 mm to IEC 61554
Depth behind panel	193 mm (incl. terminals)
Panel cut-out	138 ^{+1.0} mm × 138 ^{+1.0} mm to IEC 61554
Panel thickness	2 to 40 mm
Housing mounting	in panel to DIN 43834
Operating position	unrestricted, but taking into account the viewing angle of the screen, horizontally ±65°, vertically +40° to -65°
Enclosure protection	to EN 60529 Category 2, front IP65, rear IP20
Weight	approx. 3.5 kg

Approvals/marks of conformity

Mark of conformity	Testing laboratory	Certificates / certification numbers	Test basis	valid for
c UL us	Underwriters Laboratories	E 201387	UL 61010-1 CAN/CSA-C22.2 No. 61010-1	the flush-mounted instrument; not in conjunction with extra code 350
II 2G Ex px IIC II 2D Ex pD 21 IP65	electrosuisse	SEV 08 ATEX 0155 U	EN 1127-1:2007 EN 60079-0:2006 EN 60079-2:2007 EN 61241-0:2006 EN 61241-4:2006	the flush-mounted instrument; only in conjunction with extra code 444 and without extra code 350



Instrument description

Hardware

The paperless recorder is built to a modular design. The basic type consists of a PSU board (incl. relays) and a CPU board (incl. Ethernet and RS232/RS485 interfaces and an RS232 interface for barcode reader and USB interface connection).

Module slots 1, 2 and 3 can be fitted with input modules, each with 6 analog inputs or 3 analog inputs and 8 binary inputs/outputs. Alternatively, module slot 3 can be fitted with a relay module that has 6 relays.

Optionally, the PSU board can be equipped with a PROFIBUS-DP interface.

Data recording

Measurements are acquired continuously in a 125msec sampling cycle. Based on these measurements, reports are compiled and limits checked.

The measurements are transferred to the main memory of the instrument, according to the programmable storage cycle and stored value (maximum, minimum, average, min&max, instantaneous value or economy mode).

The paperless recorder saves the data in groups, and an input can be assigned to several groups (maximum 9).

Main memory (SRAM)

The data stored in the SRAM are regularly copied to the internal memory in 20 kbyte blocks.

Internal memory

When a block in the main memory has been filled, it is copied to the internal memory. The internal memory has a capacity of

Every write action is monitored, so that any errors in saving the data can be immediately identified.

The instrument monitors the capacity of the internal memory and activates one of the "memory alarm" signals when the capacity falls below the configurable residual capacity level. These signals can be used, for instance, to operate the alarm relay.

The memory is written as a ring memory, i. e. when the memory is full, the oldest data are automatically overwritten by the new data. Data from the internal memory can be shown as a history presentation on the recorder. The size of the history memory can be configured.

Data transfer to the PC

Data transfer from the paperless recorder to a PC is made by means of the external CompactFlash memory card (not available with stainless steel front), the USB memory stick or via one of the interfaces (USB device, RS232, RS485, Ethernet).

Data security

The data are stored in coded form in a proprietary format. This ensures a high level of data security.

If the paperless recorder is disconnected from the supply, then:

- RAM and clock time are buffered by a lithium battery (ex-factory) ≥ 10 years or with a storage capacitor ≥ 2 days (ambient temperature -40 to $+45$ °C),
- measurement and configuration data in the internal memory will not be lost.

Recording duration

Depending on the configuration of the instrument, the duration of the recording can vary over a considerable range (from a few days up to several months).

Report

For each channel of a group, a report (maximum/minimum/average or integrator) can be run over defined periods.

Batch reports

Up to three batch reports can be created simultaneously in the recorder. The measurement data, start, end and duration of each batch can be displayed together with a batch counter and freely definable texts, both on the recorder and within the PC Evaluation Software PCA3000.

On request, a barcode reader can be used to start batches and read in batch texts.

Limit checkline

changeover of operating mode

Over/underlimit conditions trigger alarms. An alarm can be used, for instance, as a control signal for changing over the operating mode. The storage cycle and stored value can be configured separately for all three operating modes.

With the help of the alarm delay function, brief occurrences or over/underlimit conditions can be filtered out, with the result that no alarm is generated.

Normal operation

If the instrument is **not** in timed or event operation, normal operation is active.

Event operation

Event operation is activated/deactivated by a control signal (binary input, group/combination alarm, ...). As long as the control signal is active, the instrument is in event operation.

Timed operation

Timed operation is active on a daily basis within a programmable time period. The operating modes have different priorities.

Counters/integrators

27 additional internal channels are available for use as counters, integrators, operating time counters or for flow measurements. These counters are controlled through the binary inputs, the alarms, or via the logic channels. The analog channels can be used for the integrators.

The numerical indication is shown in a separate window, with a maximum of 9 digits. The acquisition period can be selected as: periodic, daily, weekly, monthly, yearly as well as external, total (overall count) or daily from to a maximum of 6 binary inputs are available as high-speed counters with a 10 kHz sampling cycle rate.

Math/logic module (extra code)

The module for math and logic (18 channels each) enables, for instance, the combination of analog channels with one another, and also the combination of analog channels with counters and binary inputs. The operators available for formulae are: +, -, *, /, SQRT(), MIN(), MAX(), SIN(), COS(), TAN(), **, EXP(), ABS(), INT(), FRC(), LOG(), LN(), humidity, moving average or !, &, |, ^, as well as (and). The math and logic module can only be configured through the setup program.

Operation and configuration

On the recorder

The instrument is configured from the control knob (or with stainless steel front, from the touchpad) on the front panel under menu guidance.

Shift current menu position (cursor) to the left or upwards.

Shift current menu position (cursor) to the right or downwards.

When the control knob is pressed, the current function is executed.

Example:




Rotate control knob to the left.




Press control knob.

Result: The menu for the alarm and event list is called up.



Rotate control knob to the left.



Press control knob.

Result: The menu for the alarm and event list is closed again.




H Integrated user lists (different users with different authorizations) protect the recorder against unauthorized access.

Through the setup program

As an alternative to the configuration from the control knob on the recorder, the instrument can also be configured through the setup program.

Communication between the setup program and the paperless recorder is made through the:

- USB device interface
- serial interface
- Ethernet interface
- CompactFlash memory card or
- USB memory stick



The configuration data can be archived on a data storage medium and output to the printer.

Operating language

Two languages (see order details) are integrated in the instrument ex-factory. The setup program is used to exchange the operator language.

The languages available at the moment are: English, French, German, Russian, Japanese, Chinese, Italian, Romanian, Czech, Hungarian, Polish and Greek.

Other language versions (with Unicode capability) can be created.

Web server

The web server is integrated in the paperless recorder as standard. Four different modes of presentation are available:


- online visualization
- three freely programmable HTML pages
- current batch reports
- 4-way view (1 to 4 recorders or different visualizations)



On the PC side, the web server can be addressed with the (Microsoft®) Internet Explorer. For visualizing graphics, an SVG Viewer (from Adobe®, for instance) must be installed on the PC in addition to the Internet Explorer.

Process images (editor)


The setup program can create process images and transfer them to the paperless recorder for display. Up to 25 objects (images, analog channels, binary channels, texts, ...) can be used in a process image.



One process image is integrated in the paperless recorder ex-factory.


Visualization on the instrument

Operator level




- Selection of visualization

Vertical diagram




- Recorder chart presentation of analog and binary channels
- Display of scaling and limit markers of a channel (can be switched on/off)
- Numerical display of current analog channels

Bar graph presentation




- Bar graph presentation of analog channels
- On/ Off presentation of binary channels
- Display of current analog channels with scaling and limit markers
- Color change of bar graph to red when limits are infringed

Numerical presentation




- Large numerical presentation of analog channels, including the channel name and description
- Each analog channel can be switched to the foreground
- On/ Off presentation of binary channels

Numerical 1-channel presentation



- Clear presentation of an analog channel
- An analog input is shown simultaneously as a bar graph and a number
- Display of channel name and description
- Display of scaling and limit markers


Process image



- Freely configurable presentation (through the setup program) of analog and binary signals with background pictures
- One process image for each group




Binary presentation




- On/ Off presentation of binary channels

Report




- Display of different reports for the analog channels of a group
- Details of minimum, maximum, average/ integral values and time period
- Display of the previous report

Batch reports




- 3 batches documented simultaneously
- Changeover between current and completed batch reports
- Electronic signature is possible
- Batch texts via interface and barcode reader, among others

Counter/integrator presentation




- Presentation of up to 27 counters or integrators
- Changeover between individual and overall display
- Display of the current and the most recently completed count

Group selection



- Up to 9 groups are configurable
- Up to 6 analog and 6 binary channels can be shown for each group
- Measurement signals can be used in several groups

History presentation



- All stored measurement data are shown as curves at different zoom levels
- Display of scaling and limit markers of a channel
- Numerical display of the measurements of the analog channels at the cursor position
- Shifting of the visible section within the stored measurement data

Presentation of alarm lists

Date	Time	Description
2006/07/04	09:47:22	Alarm Lim02
2006/07/04	09:47:15	Alarm Lim01
2006/07/04	09:47:15	I/O 9 not calibrated
2006/07/04	09:47:15	High Alarm A108
2006/07/04	09:47:15	I/O 8 not calibrated
2006/07/04	09:47:15	I/O 7 not calibrated
2006/07/04	09:47:15	High Alarm A102


- Display of current alarms
- For the instrument as a whole or batch-related
- Up to 150 entries visible on the recorder

Presentation of event lists

Date	Time	Description
2006/07/04	09:35:19	CF card removed
2006/07/04	09:35:19	CF card in place
2006/07/04	09:35:16	CF card removed
2006/07/04	09:34:42	POWER ON
2006/07/04	09:33:42	POWER OFF
2006/07/04	09:26:29	Batch 01 end
2006/07/04	09:25:28	Batch 01 start
2006/07/04	09:05:31	NEW CONFIGURATION


- Display and storage of events and alarms
- For the instrument as a whole or batch-related
- Up to 150 entries visible on the recorder

Configuration




- Configuration on the recorder itself, by rotating and pressing the control knob
- Configuration through the setup program

Visualization through the web browser



- Online visualization of a recorder
- Selection of (max.) three customized HTML pages (created on request)



- Navigation through the different recorder visualizations (curves, bar graph, text, process, ...)




- Max. four recorders or four different visualizations simultaneously

PC programs


PC Evaluation Software (PCA3000)

The PC Evaluation Software (PCA3000) is a program which runs under Windows 2000/XP, and is used to manage, archive, visualize and evaluate the recorder data.



- The data from differently configured instruments are recognized by the PC Evaluation Software and stored in an archive database. All management is fully automatic. The user only has to manually allocate an identifier (supplementary description).
- The user can at any time gain access to certain data sets which can be distinguished by the identifier. It is also possible to restrict the time periods to be evaluated.
- Any analog or binary channels of a paperless recorder (even from different groups) can subsequently be combined into PCA groups in PCA3000.
- Since each group is displayed in a separate window, several groups can be shown simultaneously on the screen and compared.
- Operation by mouse or keys.
- Using the export filter, it is possible to export the stored data, so that they can be processed in other programs such as Excel.
- The PC Evaluation Software PCA3000 has network capability, i.e. several users can obtain data from the same archive file (*.177) in a network directory, independently of each other.

PCA Communications Software (PCC)



1. Retrieve measurement data from the recorder.
2. Store measurement data in archive files (*.177).
3. Activate "automatic printout" in PCA3000.
The print template is selected within PCC.
4. Read the print template. Print templates are created within PCA3000.
5. Data transfer from archive.
6. Determine the content defined in the print template.
7. Use the determined content in the defined design.
8. Output the completed design in the defined formats.

- Data can be read out from the recorder via the USB device interface, the serial interface (RS232/RS485) or via the Ethernet interface; the data can be read manually or automatically (e.g. daily at 23.00 hrs)
- Data can also be retrieved via remote control, through a modem

PC Security Manager (PCS)

Software for the administration of access control. This software is only accessible to administrators.

PC Audit-Trail Manager (PCAT)

Software for the documentation of PC operational actions that could lead to alterations in data recording.



Interfaces

- USB interfaces (standard)
- RS232/RS485 interface (standard)
- RS232 interface for barcode reader (standard)
- Ethernet interface (standard)
- PROFIBUS-DP interface (extra code)

	USB Host/Device	RS232 RS485	Ethernet	PROFIBUS-DP	External CF card
Read current measurement data	yes (device only)	yes	yes	yes	no
Write current measurement data	no	yes	yes	yes	no
Read out stored measurement data	yes	yes	yes	no	yes
Read/write configuration	yes	yes	yes	no	yes
Write user list	yes	yes	yes	no	yes

USB interfaces

With USB interfaces, a distinction is made between the host and the device interface.

A USB memory stick can be attached to the host interface. The device interface, in conjunction with a standard commercial USB cable, is used to operate the setup program. The paperless recorder without stainless steel front has host and device interfaces connected in parallel on both the front and back panels, of which only one of each type can ever be used. The paperless recorder with stainless steel front has only one host and one device interface at the rear panel.

RS232/RS485 interface

Current process data, as well as specific device data, can be read out via the RS232 or RS485 interface.

Data saved to the internal memory can also be read out in conjunction with the PC Evaluation Software PCA3000 and the PCA Communications Software (PCC).

The RS232 interface permits a maximum lead length of 15 m, the RS485 interface 1.2 km. Connection is by a 9-pin SUB-D connector on the back of the instrument. Modbus (master and slave) protocols are available, and the transmission mode used is RTU (Remote Terminal Unit).

RS232 for barcode reader

A barcode reader can be attached to the interface. The barcode reader can be used to start or stop batch reporting, and to set batch texts (customer information, batch number...).

The barcode reader can also be operated via the RS232/RS485 interface, and the RS232 interface for the barcode reader can also be used as a Modbus master or slave.

Ethernet interface

The Ethernet interface can be used in local networks for the communication between the recorder and the setup program and the PCA Communications Software. The IP address is set permanently through the configuration on the instrument or in the setup program, or can be automatically received from a DHCP server.

The integrated web server allows simultaneous access by several PCs to 3 HTML and 3 batch pages.

Transmission protocol: TCP/IP
 Network type: 10BaseT, 100BaseT

PROFIBUS-DP interface

The recorder can be integrated into a fieldbus system according to the PROFIBUS-DP standard via the PROFIBUS-DP interface. This PROFIBUS version is especially designed for communication between automation systems and distributed peripheral devices at the field level.

Data are transmitted serially according to the RS485 standard, with a maximum 12 Mbits/sec.

Using the project design tool that is included in the delivery (GSD generator; GSD = device master file), an application-specific GSD file is created, which is used to integrate the recorder into the fieldbus system.

External CompactFlash memory card (CF)

For paperless recorders without stainless steel front, the external CompactFlash memory card (CF) is used to transfer the data from the internal memory to the PC. Configuration data can be created on the PC and then transferred to the recorder by means of the memory card.

On the PC side, data on the card is accessed using a read/write device (CompactFlash reader/writer).

External inputs via interface

The paperless recorder can acquire and store up to 24 external analog inputs and 24 binary inputs.

Furthermore, the interfaces can be used to enter comments in the event list of the recorder.

Stainless steel front (extra code 444)

The paperless recorder with extra code 444 (without extra code 350) may be installed in switch cabinets with at least a simplified pressurized enclosure. Under these conditions, use in a potentially explosive atmosphere (max. zones 1 and 21) is authorized from the front.

Notes on installation in Installation Instructions B 706585.4.1 must be complied with and followed.

Paperless recorders with authorization for explosion hazard areas, carry the following mark on the nameplate attached to the instrument.

II 2G Ex px IIC


II 2D Ex pD 21 IP65

Caution: If extra code 444 is present, the CompactFlash memory card can no longer be used for external storage. Measurement data can be read out via one of the interfaces or via a USB memory stick (from the back).

Connection diagram

Rear view with pluggable screw terminals

Instrument variant 1




Module slot 3 (top)
 fitted with one relay card

Module slot 2 (middle)
 fitted with 6 analog channels or
 3 analog channels and
 8 binary inputs/outputs

Module slot 1 (bottom)
 fitted with 6 analog channels or
 3 analog channels and
 8 binary inputs/outputs




Instrument variant 2















Module slot 3 (top)
 fitted with 6 analog channels or
 3 analog channels and
 8 binary inputs/outputs

Module slot 2 (middle)
 fitted with 6 analog channels or
 3 analog channels and
 8 binary inputs/outputs


Module slot 1 (bottom)
 fitted with 6 analog channels or
 3 analog channels and
 8 binary inputs/outputs

Terminal assignment	Connector	Diagram
Supply		
Supply as on nameplate	Connector 4 L1 (L+) N (L-) PE 	L1 N PE L1 N PE
Analog inputs		
Thermocouple	 Connectors 8 to 11 (input 1 to 12) for instrument variant 1 or Connectors 8 to 13 (input 1 to 18) for instrument variant 2 	1 2 3 4
RTD in 2-wire circuit		1 2 3 4
RTD in 3-wire circuit		1 2 3 4
RTD in 4-wire circuit		1 2 3 4
Resistance transmitter		
Potentiometer in 2-wire circuit		1 2 3 4
Potentiometer in 3-wire circuit		1 2 3 4
Potentiometer in 4-wire circuit		1 2 3 4
Voltage input 0 to 1 V		1 2 3 4 U _x = 0 to 1 V —
Voltage input 0 to 10 V		1 2 3 4 U _x = 0 to 10 V —
Current input	1 2 3 4 I _x —	

Terminal assignment	Connector	Diagram
<p>Binary Inputs/Outputs Configuration (through the setup program or on the instrument) defines which are binary inputs and which are outputs.</p>		
<p>B1 to B8</p> <p>voltage-controlled LOW = -3 to +5V DC LOW = 12 to 30V DC</p> <p>internal power supply 24V/60mA (U_{out})</p> 	<p>Connector 9 only on modules with 3 analog inputs</p> <p>B1 binary input/ output 1</p> <p>to</p> <p>B8 binary input/ output 8</p> <p>U_{in+} external power supply</p> <p>U_{in-} ground</p> <p>U_{out+} +24V internal power supply</p> <p>U_{out-} ground</p>	<p>B1 B2 B3 B4 B5 B6 B7 B8 U_{in+} U_{in-} U_{out+} U_{out-}</p> <p>Load</p> <p>24V external power supply</p> <p>Example: Connecting a load to binary output 4 (B4) and a solid state relay to binary output 3 (B3) requires an external power supply.</p> <p>Diagram of the connector:</p> <p>B1 B2 B3 B4 B5 B6 B7 B8 U_{in+} U_{in-} U_{out+} U_{out-}</p>
<p>B9 to B16</p> <p>voltage-controlled LOW = -3 to +5V DC LOW = 12 to 30V DC</p> <p>internal power supply 24V/60mA (U_{out})</p> 	<p>Connector 11 only on modules with 3 analog inputs</p> <p>B9 binary input/ output 9</p> <p>to</p> <p>B16 binary input/ output 16</p> <p>U_{in+} external power supply</p> <p>U_{in-} ground</p> <p>U_{out+} +24V internal power supply</p> <p>U_{out-} ground</p>	<p>B9 B10 B11 B12 B13 B14 B15 B16 U_{in+} U_{in-} U_{out+} U_{out-}</p> <p>Example: Binary input 12 (B12) is operated from the internal power supply.</p> <p>Diagram of the connector:</p> <p>B9 B10 B11 B12 B13 B14 B15 B16 U_{in+} U_{in-} U_{out+} U_{out-}</p>
<p>B17 to B24</p> <p>voltage-controlled LOW = -3 to +5V DC LOW = 12 to 30V DC</p> <p>internal power supply 24V/60mA (U_{out})</p> 	<p>Connector 13 only for instr. variant 2 and for modules with 3 analog inputs</p> <p>B17 binary input/ output 17</p> <p>to</p> <p>B24 binary input/ output 24</p> <p>U_{in+} external power supply</p> <p>U_{in-} ground</p> <p>U_{out+} +24V internal power supply</p> <p>U_{out-} ground</p>	<p>B17 B18 B19 B20 B21 B22 B23 B24 U_{in+} U_{in-} U_{out+} U_{out-}</p> <p>Example: Binary input 20 (B20) is operated from the internal power supply.</p> <p>Diagram of the connector:</p> <p>B17 B18 B19 B20 B21 B22 B23 B24 U_{in+} U_{in-} U_{out+} U_{out-}</p>


Terminal assignment	Connector	Diagram
Relay outputs		
Relay 1 changeover (SPDT)	Connector 1 	12 11 13
Relay 2 changeover (SPDT)		22 21 23
Relay 3 changeover (SPDT)		32 31 33
Relay 4 changeover (SPDT)		42 41 43
Relay 5 changeover (SPDT)		52 51 53
Relay 6 changeover (SPDT)		62 61 63
Relay 7 changeover (SPDT)		72 71 73
Interfaces		
RS232 for barcode reader 9-pin SUB-D socket connector	Connector 2 	2 RxD Receive Data 3 TxD Transmit Data 5 GND Ground
PROFIBUS-DP 9-pin SUB-D socket connector (extra code)	Connector 3 	3 RxD/TxD-P Receive/Transmit Data-Pos. B conductor 5 DGND Ground for data transmission 6 VP Supply voltage-Pos. 8 RxD/TxD-P Receive/Transmit Data-Neg. A conductor
USB host interface for connecting memory sticks	Connector 5 	The recorder without stainless steel front also has a USB host interface on the front panel, connected in parallel. The two interfaces cannot both be operated at the same time.
Ethernet RJ45 socket connector	Connector 6 	1 TX+ Transmit Data + 2 TX- Transmit Data - 3 RX+ Receive Data + 6 RX- Receive Data -
RS232 9-pin SUB-D socket connector (switchable to RS485)	Connector 7 	2 RxD Receive Data 3 TxD Transmit Data 5 GND Ground
RS485 9-pin SUB-D socket connector (switchable to RS232)	Connector 7 	3 TxD+/RxD+ Transmit/Receive Data + 5 GND Ground 8 TxD-/RxD- Transmit/Receive Data -
USB host interface for connecting a PC	Connector 15 	The recorder without stainless steel front also has a USB device interface on the front panel, connected in parallel. The two interfaces cannot both be operated at the same time.

Overview of the electrical isolation




Dimensions


Recorder with die-cast zinc front




Recorder with stainless steel front (extra code 444)



Panel cut-out



Universal carrying case option - TG-35





Order details

(1) Basic type	
706585	Paperless recorder with Ethernet, USB and RS232/RS485 interfaces and RS232 interface (to connect a barcode reader) and one relay
(2) Software	
0	No software package
1	With software package (setup program incl. USB cable, PCA3000, PCC, PCS, PCAT)
(3) Language for instrument texts	
8	Factory setting (German/English)
9	Set to customer specification
(4) Module slot 1	
0	not used
2	3 analog inputs and 8 binary inputs/outputs
3	6 analog inputs
(5) Module slot 2	
0	not used
2	3 analog inputs and 8 binary inputs/outputs
3	6 analog inputs
(6) Module slot 3	
0	not used
1	6 relay outputs
2	3 analog inputs and 8 binary inputs/outputs
3	6 analog inputs
(7) Supply	
25	AC/DC 20 to 30 V, 48 to 63 Hz
33	AC 100 to 240 V +10/-15 %, 48 to 63 Hz
(8) Extra codes memory	
020	Lithium battery for memory buffering (ex-factory)
021	Storage capacitor
(9) Extra codes	
.	not used
260	Math and logic module
(10) Extra codes housing	
.	not used
350	Universal carrying case TG-35 ^a
444	Stainless steel front with touchpad
(11) Extra codes	
.	without extra codes
267	PROFIBUS-DP interface

^a This extra code is available in combination with voltage supply AC 100 to 240 V, not with low supply voltage. UL and ATEX approvals not applicable. The protection type in the carrying case corresponds to IP20, outside IP20D.

Order code (1) (2) (3) (4) (5) (6) (7) (8) (9) (10) (11)
Order example 706585 / - - / , , ,

List extra codes in sequence, separated by commas.



Standard accessories

- 1 Installation instructions B706585.4 (B706585.4.1 with extra code 444) and 1 Operating instructions B706585.1
- 4 mounting brackets
- 1 control panel seal
- 1 CD with detailed operating instructions and additional documentation

Accessories - data sheet 709700

- PC software package consisting of:
Setup program, PC Evaluation Software (PCA3000), PCA Communications Software (PCC), PC Security Manager (PCS), and PC Audit-Trail Manager (PCAT). Please specify all version numbers when placing repeat orders.
- CompactFlash memory cards and USB memory sticks
The CF cards and memory sticks specified by INTEMPCO are tested and designed for industrial applications. The correct use with other brands cannot be guaranteed.
- For further accessories see data sheet 709700